


Solenoids

AES-1511-201-12 (AES-F503)

AES-1511-201-24 (AES-F504)



Starter Solenoid 85Amps
Grounded base, Flat bracket.
4 terminals



AES-1511-205-12 (AES-E205S)

AES-1511-205-24


Starter Solenoid
Extra Heavy Duty.
200Amps continuous and 600Amps in rush.
4 silver alloy contacts (2 normally open)
Use in mining, logging and construction equipments.



AES-1511-202-12 (AES-F503-3T)


AES-1511-202-24 (AES-F504-3T)

Starter Solenoid 85Amps
Grounded base, Flat bracket.
3 terminals



AES-1511-207-2


Starter Solenoid
SPST, normally open.
12V 100Amps continuous and 400Amps in rush.
Silver contacts.
Insulated Type.



AES-1511-203-12 (AES-C172)

AES-1511-203-24 (AES-C173)

Starter Solenoid 85Amps
Insulated Type.
Operating coil connections: 2 small terminals.
Brass Contacts.



AES-1511-211

Forward & Reverse module
For Lift and Tarp operations, anywhere an up/down, in/out, clockwise/counterclockwise control is needed.
Dynamic braking stops the motor when the switch returns to OFF.
Automatically reverses the direction of the motor when the appropriate control circuit is energized.
Rating:
12VDC 50A continuous.
12VDC 70A intermittent
Max ON time 5 mins, OFF time 3 mins.
Meet IP67



AES-1511-204-12 (AES-C172-3T)

AES-1511-204-24 (AES-C173-3T)

Starter Solenoid 85Amps
Grounded Type.
Operating coil connections: 2 small terminals.
Brass Contacts.

